



# **DIRECTIONS FOR GRILL USE**

## **START INSTRUCTIONS**

- Make sure all knobs on grill and propane tanks are in the OFF position
- Connect both propane tanks to the grill hoses
- Turn ON the propane tanks (knob on top of tank)
- Have lighter ready in hand
- Turn on left RED knob – then light at the end of left hand side of grill (small hole on the side of grill)
- Turn on each burner (Black knobs) that are to the left of the left red knob
- Turn on right RED knob – then light at the end of right hand side of grill (small hole on the side of grill)
- Turn on each burner (Black knobs) that are to the right of the right hand side red knob

## **AFTER COOKING:**

- Put cover down and let both sides burn on high for at least 15 minutes (to burn off all the grease, etc.) Use grill scraper to clean off grates.

If you are having problems with the grill, please turn everything off, disconnect everything and start again at the top. Please call the supervisor that opened pavilion for your group if you are still having difficulties.



presented by

**Department of Leisure, Family and Recreation**

Recreation Division

39 Lodge Drive ▪ 647-3084 ▪ [reconline.townofmanchester.org](http://reconline.townofmanchester.org)